

Planetary Gearheads 23/1

Gearhead Series	Reduction ratio	Number of gear stages	3D - File Name
23/1 (with ball bearings on output shaft)	3,71:1	1	23_1 1stage.stp
	9,7:1	2	23_1 2stages.stp *
	14,1:1	2	23_1 2stages.stp *
	43:1	3	23_1 3stages.stp *
	66:1	3	23_1 3stages.stp *
	86:1	3	23_1 3stages.stp *
	94:1	4	23_1 4stages.stp *
* Note: gearhead 23/1 (from ratio 9,7:1 upwards) requires also a specific flange, as per combination with following motors:	112:1	4	23_1 4stages.stp *
	134:1	4	23_1 4stages.stp *
	159:1	4	23_1 4stages.stp *
	190:1	4	23_1 4stages.stp *
2224...SR, 2230...S, 2232...SR, 2233...S and AM2224 please add 3D - file name: Flange23_1-1.stp	246:1	4	23_1 4stages.stp *
	415:1	5	23_1 5stages.stp *
	592:1	5	23_1 5stages.stp *
2237...CXR, 2342...CR, 2057...B and 2444...B please add 3D - file name: Flange23_1-2.stp	989:1	5	23_1 5stages.stp *
	1526:1	5	23_1 5stages.stp *

Conditions of Use

The FAULHABER CAD 3D-Drawings are a free service of FAULHABER MINIMOTOR SA, 6980 Croglio, Switzerland. They may only be used and distributed in a complete and unaltered form. All copy rights reserved.

Please Note: All dimensions are displayed using the metric system (millimeters). Your CAD system maybe preset to another system of measurements or dimenstions. Preset millimeter in the CAD application before importing the file!

These models are intended as a conceptual aid only. All dimensions are subject to change without notice. The most up-to-date drawings can be downloaded from the Internet at: www.faulhaber.com

Though we endeavor to maintain the accuracy of the models provided we can provide no guarantee of their accuracy. Use of the models is at your own risk.

With the use of the data you agree with the aforementioned conditions.