

Planetary Gearheads 38/1 S

Gearhead Series	Reduction ratio	Number of gear stages	3D - File Name
38/1 S (with ball bearings on output shaft)	14,1:1	2	38_1S 2stages.stp *
	43:1	3	38_1S 3stages.stp *
	66:1	3	38_1S 3stages.stp *
	134:1	4	38_1S 4stages.stp *
*Note:	159:1	4	38_1S 4stages.stp *
gearhead 38/1 S requires also a specific flange, as per combination with following motors:	246:1	4	38_1S 4stages.stp *
	415:1	5	38_1S 5stages.stp *
	592:1	5	38_1S 5stages.stp *
3056...B and 3564...B	989:1	5	38_1S 5stages.stp *
please add 3D - file name: Flange38_1S-1.stp	1526:1	5	38_1S 5stages.stp *
3242...CR, 3257...CR, 3272...CR, 3242...BX4 and 3268...BX4			
please add 3D - file name: Flange38_1S-2.stp			
3863...CR and 3890...CR			
please add 3D - file name: Flange38_1S-3.stp			

Conditions of Use

The FAULHABER CAD 3D-Drawings are a free service of FAULHABER MINIMOTOR SA, 6980 Croglio, Switzerland.
They may only be used and distributed in a complete and unaltered form. All copy rights reserved.

Please Note: All dimensions are displayed using the metric system (millimeters). Your CAD system maybe preset to another system of measurements or dimenstions. Preset millimeter in the CAD application before importing the file!

These models are intended as a conceptual aid only. All dimensions are subject to change without notice.
The most up-to-date drawings can be downloaded from the Internet at: www.faulhaber.com

Though we endeavor to maintain the accuracy of the models provided we can provide no guarantee of their accuracy.
Use of the models is at your own risk.

With the use of the data you agree with the aforementioned conditions.