

Planetary Gearheads 08/2

Gearhead Series	Reduction ratio	Number of gear stages	3D - File Name
08/2 (with sintered bearings on output shaft)	4:1	2	08_2 2stages.stp
	9,4:1	3	08_2 3stages.stp
	21,9:1	4	08_2 4stages.stp
	51,2:1	5	08_2 5stages.stp
	120:1	6	08_2 6stages.stp
	279:1	7	08_2 7stages.stp
	650:1	8	08_2 8stages.stp
	1518:1	9	08_2 9stages.stp
08/2K (with ball bearings on output shaft)	4:1	2	08_2K 2stages.stp
	9,4:1	3	08_2K 3stages.stp
	21,9:1	4	08_2K 4stages.stp
	51,2:1	5	08_2K 5stages.stp
	120:1	6	08_2K 6stages.stp
	279:1	7	08_2K 7stages.stp
	650:1	8	08_2K 8stages.stp
	1518:1	9	08_2K 9stages.stp

Conditions of Use

The FAULHABER CAD 3D-Drawings are a free service of FAULHABER MINIMOTOR SA, 6980 Croglio, Switzerland. They may only be used and distributed in a complete and unaltered form. All copy rights reserved.

Please Note: All dimensions are displayed using the metric system (millimeters). Your CAD system maybe preset to another system of measurements or dimenstions. Preset millimeter in the CAD application before importing the file!

These models are intended as a conceptual aid only. All dimensions are subject to change without notice. The most up-to-date drawings can be downloaded from the Internet at:

Though we endeavor to maintain the accuracy of the models provided we can provide no guarantee of their accuracy. Use of the models is at your own risk.

With the use of the data you agree with the aforementioned conditions.