

## Spur Gearheads 22/2

Gearhead Series	Reduction ratio	Number of gear stages	3D - File Name
22/2 (with ball bearings on output shaft)	3,1:1	2	22_2 2stages.stp
	5,4:1	2	22_2 2stages.stp
	9,7:1	3	22_2 3stages.stp
	17,2:1	4	22_2 4stages.stp
	30,7:1	4	22_2 4stages.stp
	54,6:1	5	22_2 5stages.stp
	97,3:1	5	22_2 5stages.stp
	173:1	6	22_2 6stages.stp
	308:1	6	22_2 6stages.stp
	548:1	7	22_2 7stages.stp
	975:1	7	22_2 7stages.stp
	1734:1	8	22_2 8stages.stp
	3088:1	8	22_2 8stages.stp
	5490:1	9	22_2 9stages.stp
	9780:1	9	22_2 9stages.stp
	17386:1	10	22_2 10stages.stp
	30969:1	10	22_2 10stages.stp

## Conditions of Use

The FAULHABER CAD 3D-Drawings are a free service of FAULHABER MINIMOTOR SA, 6980 Croglio, Switzerland. They may only be used and distributed in a complete and unaltered form. All copy rights reserved.

Please Note: All dimensions are displayed using the metric system (millimeters). Your CAD system maybe preset to another system of measurements or dimenstions. Preset millimeter in the CAD application before importing the file!

These models are intended as a conceptual aid only. All dimensions are subject to change without notice. The most up-to-date drawings can be downloaded from the Internet at: [www.faulhaber.com](http://www.faulhaber.com)

Though we endeavor to maintain the accuracy of the models provided we can provide no guarantee of their accuracy. Use of the models is at your own risk.

With the use of the data you agree with the aforementioned conditions.